



# ELECTRIC ICE SHAVER

Instruction Manual



Register this and other Focus Electrics products through our website:  
[www.focuselectrics.com](http://www.focuselectrics.com)

Important Safeguards.....	2
Precautions For Use Around Children.....	2
Electricity Precautions.....	3
Using Your Ice Shaver.....	4
Warranty.....	7

**SAVE THIS INSTRUCTION MANUAL FOR FUTURE REFERENCE**

# IMPORTANT SAFEGUARDS



## CAUTION

**To prevent personal injury or property damage, read and follow all instructions and warnings.**

When using electrical appliances, basic safety precautions should always be followed including the following:

- Read all instructions, including these important safeguards and the care and use instructions in this manual.
- Do not use appliance for other than intended use.
- The use of accessory attachments not recommended by Focus Electrics may cause fire, electric shock or injury.
- Do not operate if the appliance is not working properly or if it has been damaged in any manner. For service information see warranty page.
- Do not leave unit unattended while plugged into an electrical outlet.
- Do not attempt to repair this appliance yourself.
- **For household use only.**



## CAUTION

**To prevent personal injuries, read and follow all instructions and warnings.**

### OPERATING PRECAUTIONS

- Blades are sharp. Use extreme caution during assembly, while operating, disassembly and cleaning.
- Do not use if blades are broken, cracked or loose.
- Do not leave appliance unattended while it is operating.
- Avoid contacting moving parts.
- Do not use this appliance on the stovetop, under broiler, in the oven, in the refrigerator or freezer.
- Do not run this appliance continuously for more than 5 minutes as overheating may occur. Allow motor to cool down before repeat usage.
- Do not run machine without ice in the Shaver Bowl as damage to appliance may occur.
- Never place fingers or other utensils into the feed or discharge areas.
- Always check ice hopper for presence of foreign objects before using.



## CAUTION

**To prevent electrical shock, personal injury or property damage, read and follow all instructions and warnings.**



### ELECTRICITY PRECAUTIONS

- To protect against electric shock, do not immerse cord, plugs, or other electric parts in water or other liquids.
- Do not operate any appliance with a damaged cord or plug.
- Do not use this appliance outdoors.
- Always unplug the appliance from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts and before cleaning.
- A short power-supply cord is provided to reduce risks resulting from becoming entangled in or tripping over a longer cord.
- Longer detachable power-supply cords or extension cords are available and may be used if care is exercised in their use. While use of an extension cord is not recommended, if you must use one, the marked electrical rating of the detachable power-supply cord or extension cord should be at least as great as the electrical rating of the appliance. If the appliance is of the grounded type, the extension cord should be a grounding-type 3-wire cord. The cord should be arranged so that it will not hang over the counter top or tabletop where it can be pulled by children or tripped over.
- This appliance has a polarized plug (one blade is wider than the other). To reduce the risk of electric shock, this plug is intended to fit into a polarized outlet only one way. If the plug does not fit fully into the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Do not attempt to modify the plug in any way.
- Do not use an outlet or extension cord if the plug fits loosely or if the outlet or extension cord feels hot.
- Do not attempt to use a voltage converter or other device to adapt this appliance to a different outlet or voltage, as damage will occur.
- Do not let cord contact a hot surface, including the stove.



## CAUTION

To prevent burns or other personal injuries to children, read and follow all instructions and warnings.

### PRECAUTIONS FOR USE AROUND CHILDREN

- Close supervision is necessary when this appliance is used by or near children.
- Do not allow cord to hang over any edge where a child can reach it. Arrange cord to avoid pulling, tripping or entanglement.


## SAVE THESE INSTRUCTIONS

### WELCOME TO THE REFRESHING WORLD OF SHAVED ICE

You'll love your new Back To Basics<sup>®</sup> Ice Shaver. Inspired by rare tropical snows and the local shaved ice stands in Hawaii, the Back To Basics<sup>®</sup> Ice Shavers are designed to "shave" ice into mounds of soft, fluffy snow. It's a great way to entertain family and friends. The soft texture of shaved ice actually absorbs the flavoring and won't let it run to the bottom of the serving container as happens with crushed ice. No hard chips or chunks either, just smooth, cool refreshment. Combinations of fruits and flavorings are added to create delicious tropical drinks and frosty treats. Also makes attractive ice beds for appetizers, shrimp cocktail, salads, fruits, etc. Your imagination is the only limit when using the Back To Basics<sup>®</sup> Ice Shaver.

### USING YOUR ICE SHAVER

**CAUTION:** Your Back To Basics<sup>®</sup> Ice Shaver has a sharp stainless steel blade that can cut and cause injury. Keep fingers clear from blades and avoid contact at all times when using and cleaning.



**Before using for the first time** and following periods of prolonged storage, wash the Shaver Bowl in warm, soapy water, rinse and dry. Do not put in dishwasher. NEVER IMMERSE THE SHAVER MOTOR IN WATER.

When assembling, dismantling or cleaning, always ensure that the appliance is not connected to the power supply.

1. Fill a standard ice cube tray or the supplied Ice Cups with water and place in the freezer until frozen. Ice cubes work well in the Ice Shaver but may produce a slightly coarser, textured ice than the ice cup block.
2. Place the Shaver Bowl on top of the base.
3. When the ice cubes or Ice Cup blocks are frozen solid, remove from the tray or cup and place in Shaver Bowl.
4. Place a separate bowl or dish on the base to collect the shaved ice.
5. Place the shaver Motor on top of the ice, plug into an electrical outlet, and press the Power Button. The Motor will start and the ice will begin shaving.
6. Add your favorite Back To Basics® Premium Syrup, soft drink, or fresh fruit to the shaved ice and enjoy.
7. Unplug from the power supply immediately after use.
8. After shaving, there will always be a small amount of ice remaining in the machine. The ice should be discarded and the Ice Shaver dried with a soft cloth.

## COOL & EASY TREATS

**SUPER SNOW CONES** – Shave ice directly into Snow Cone Cups. Mound tops with additional “Snow” if desired. Dispense your favorite Back To Basics® Flavored Syrup directly on top of the shaved ice. Combine different syrups to create your own unique flavors. Because the shaved ice is so snowy fine, it absorbs the flavored syrup instead of it running to the bottom. This gives you a truly intense flavor sensation, all the way through! **TIP:** Use flavored ice cubes for unique snow cone tastes. Freeze fruit juice, soda, flavored yogurt, or flavored milk into cubes. Shave into cups. If desired, use Back To Basics® Syrups for added flavor.

**SLUSHES** – Place shaved ice into serving cups or glasses. Add just enough Back To Basics® Flavored Syrup to totally absorb into the shaved ice. Try one of the following variations for a delicious, cool and refreshing treat. Garnish with sliced or diced fruit.

**Soda** – Use your favorite variety such as cola, root beer, and fruit flavors. Add a twist of lemon or lime for an added “burst” of flavor.

**Fruit Juices** – Natural flavorings that are both tasty and good for you. Try apple, grape, orange, grapefruit, and cranberry or any combination for a special treat.

**Lemonade and Punch-Flavored Drinks** – Cool and refreshing flavors are great for any occasion.

**Rainbow Slush** – A colorful and fun treat. Place a layer of shaved ice in the bottom of a tall, parfait style glass; add flavoring. Add a middle layer of ice; add a different flavoring. Add a top layer of ice and another flavoring. Garnish with fruit or paper umbrellas. A great party treat!

**FRUIT WONDERS** – Mix shaved ice with fruit juice and either canned or fresh fruits. Try orange and pineapple juice with bananas. A great way to start the day or as an afternoon pick-me-up!

**OTHER SHAVED ICE USES**

Shaved ice is a great base when used in other blended drinks and smoothies. Combine with fruit, yogurt, or juices for great tasting and healthy treats.

Fresh shaved ice makes a great ice bed for seafood appetizers, such as shrimp cocktail.

## PRODUCT WARRANTY

### Appliance 1 Year Limited Warranty

Focus Electrics, LLC ("Focus Electrics") warrants this appliance from failures in the material and workmanship for one (1) year from the date of original purchase with proof of purchase, provided the appliance is operated and maintained in conformity with the provided Instruction Manual. Any failed part of the appliance will be repaired or replaced without charge at Focus Electrics' discretion. This warranty applies to indoor household use only.

This warranty does not cover any damage, including discoloration, to any non-stick surface of the appliance. This warranty is null and void, as determined solely by Focus Electrics if the appliance is damaged through accident, misuse, abuse, negligence, scratching, or if the appliance is altered in any way.

THIS WARRANTY IS IN LIEU OF ALL IMPLIED WARRANTIES, INCLUDING WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE, PERFORMANCE, OR OTHERWISE, WHICH ARE HERBY EXCLUDED. IN NO EVENT SHALL FOCUS ELECTRICS BE LIABLE FOR ANY DAMAGES, WHETHER DIRECT, INDIRECT, INCIDENTAL, FORSEEABLE, CONSEQUENTIAL, OR SPECIAL, ARISING OUT OF OR IN CONNECTION WITH THIS APPLIANCE.

If you think the appliance has failed or requires service within its warranty period, please contact the Focus Electrics Customer Service Department at (866) 290-1851 or e-mail us at [service@focuselectrics.com](mailto:service@focuselectrics.com). Return shipping fees are non-refundable. A receipt proving original purchase date will be required for all warranty claims. Hand-written receipts are not accepted. Focus Electrics is not responsible for returns lost in transit.

**Valid only in USA and Canada**

## REPLACEMENT PARTS

Replacement parts, if available, may be ordered directly from Focus Electrics online at [www.focuselectrics.com](http://www.focuselectrics.com), or you may call or e-mail the service department at the number/e-mail address listed above, or by writing to us at:

Focus Electrics, LLC  
Attn: Customer Service  
P. O. Box 2780  
West Bend, WI 53095

Be sure to include the catalog/model number of your appliance (located on the bottom/back of the unit) and a description and quantity of the part you wish to order. Along with this include your name, mailing address, Visa/MasterCard number, expiration date and the name as it appears on the card. Checks can be made payable to Focus Electrics, LLC. Call Customer Service to obtain purchase amount. Your state's sales tax and a shipping/processing fee will be added to your total charge. Please allow two (2) weeks for delivery.

This manual contains important and helpful information regarding the safe use and care of your new Focus Electrics product. For future reference, attach dated sales receipt for warranty proof of purchase and record the following information:

Date purchased or received as gift: \_\_\_\_\_

Where purchased and price, if known: \_\_\_\_\_

Item number and Date Code (shown bottom/back of product): \_\_\_\_\_

